

Service Info

iClimber Series

GER

Batteriewechsel und komplettes Reset

Nach der Entnahme der schwachen Batterie beim Batteriewechsel ist mind. 3 Min. zu warten, bevor die neue Batterie eingelegt wird. So ist sicher gestellt, dass der Reststrom (sog. Streukapazität) in der Uhr vollständig abgebaut.

Sollten doch noch Fehlfunktionen auftreten, kann die Uhr komplett zurück gesetzt werden. Führen Sie dazu die folgenden Schritte aus:

- 1) Gehen Sie in die Uhrzeit-Anzeige, in der unteren Zeile sollte der Wochentag angezeigt werden.
- 2) Drücken und halten Sie alle 4 Tasten gedrückt bis alle LCD Segmente angezeigt werden.
- 3) Drücken Sie kurz die „Stop“ Taste -> „batt“ für den Batterietest wird angezeigt und es ertönt ein Piepston
- 4) Drücken Sie die „Start“ Taste -> Barometer und Temperatur Messung wird angezeigt
- 5) Drücken Sie die „EL“ Taste -> verschiedene Zahlen werden angezeigt
- 6) Drücken Sie die „Mode“ Taste -> die Uhrzeit Anzeige erscheint
- 7) Drücken und halten Sie die „EL“ Taste, bis in der Anzeige „RESET“ erscheint
- 8) Drücken Sie die „Mode“ Taste -> ein kurzer Piepton ertönt und die Uhr geht in den Schlafmodus (keine Anzeige mehr).
- 9) Drücken und halten Sie eine beliebige Taste bis die Uhr sich wieder aktiviert.

Nun ist die Uhr zurück gesetzt in den Originalzustand.

ENG

Battery Change and Complete Reset

After taking out the weak battery please wait at least 3 minutes before inserting the new battery. This makes sure that any left current will drain out (no capacitor effect).

In case malfunction still occur the watch can be reset completely by the following steps:

- 1) Go to the time menu, in the lower line the week day should be indicated.
- 2) Press and hold all 4 buttons at the same time for 2 seconds -> all LCD segments will light up
- 3) Press (just short) the "Stop" button -> battery test will be shown and a beep sound rings
- 4) Press the "Start" button -> barometer and temperature readings are shown
- 5) Press the "EL" button -> figures in all 3 lines will be shown
- 6) Press the "Mode" button -> time screen is shown
- 7) Press and hold for 3 seconds the "EL" button, until the screen shows RESET
- 8) Press the "Mode" button -> no screen anymore, the watch is in sleep mode now
- 9) Press and hold any key to active the watch.

Now the watch is reset into its original condition.